

HOLDEN V12.0

Table of Contents

1	Vehicle models covered.....	1
2	Vehicle systems covered	2
3	Vehicle Special Function covered	3

1 Vehicle models covered

Model	Year
V2 Series	2002
V2 Series	2003
V2 Series	2004
VE and WM Series	2007
VE and WM Series	2008
VE and WM Series	2009
VE and WM Series	2010
VE and WM Series	2011
VE and WM Series	2012
VR Commodore	-1996
VS Commodore	-1996
VS Commodore	1998
VS Commodore	1999
VT Commodore	1997
VT Commodore	1998
VT Commodore	1999
VT Commodore	2000
VU Utility	2001
VU Utility	2002
VX Commodore	2001
VX Commodore	2002
VY Series	2003
VY Series	2004
VZ and WL Series	2005
VZ and WL Series	2006
WH Statesman & Caprice	1999
WH Statesman & Caprice	2000
WH Statesman & Caprice	2001
WH Statesman & Caprice	2002
WH Statesman & Caprice	2003
WK Series	2004

2 Vehicle systems covered

System	DTC	Data List	Active Test	Special Func
(GEN III Automatic Transmission)	X	X	X	
(V8 GEN III)	X	X	X	
Body(Audio System)	X	X	X	
Body(Audio System)	X	X	X	X
Body(BCM (Body Control Module))	X	X	X	
Body(Body Control Module)	X	X	X	X
Body(Electronic Climate Control)	X	X	X	
Body(HVAC (Heating Ventilation And Cooling))	X	X	X	X
Body(HVAC(Heating Ventilation and Cooling))	X	X	X	X
Body(IPC (Instrument Panel Cluster))	X	X	X	X
Body(IPC(Instrument Panel Cluster))	X	X	X	X
Body(Inflatable Restraint Sensing&Diag.Module)	X	X	X	
Body(Instrument)	X	X	X	X
Body(Occupant Climate Control)	X	X	X	
Body(Park Assist)	X	X	X	
Body(Powertrain Interface Module)	X	X	X	
Body(RFA (Remote Function Actuator))	X	X		
Body(SDM (Sensing and Diagnostic Module))	X	X		
Body(SRS)	X	X		
Body(Theft Deterrent)	X	X		
Chassis(ABS/ETC)	X	X	X	
Chassis(ABS/TC/ESP 8.0)	X	X	X	
Chassis(EBCM (Electronic Brake Control Module))	X	X	X	
Chassis(EBCM (Electronic Brake Control Module))	X	X	X	X
Engine(V6 Engine)	X	X	X	X
Engine(V6 LPG)	X	X	X	
Engine(V6 Supercharged)	X	X	X	
Engine(V6)	X	X	X	
Engine(V8 GEN III)	X	X	X	
Engine(V8 GEN III)	X	X	X	X
Engine(V8 GEN IV)	X	X	X	X
Engine(V8 GENIV)	X	X	X	
Engine(V8)	X	X	X	
Infotainment System(Audio System)	X	X	X	
Infotainment System(SIC (Secondary Information Centre))	X	X		X
SIC (Secondary Information Centre)	X	X		X
Transmission(Automatic Transmission)	X	X	X	
Transmission(Automatic Transmission)	X	X	X	X
Transmission(GEN III Automatic Transmission)	X	X	X	

3 Vehicle Special Function covered

System	Special Function
Body(Audio System)	Reset Service Interval
Body(Body Control Module)	Antenna Height Memory
Body(Body Control Module)	Approach Illumination
Body(Body Control Module)	BCM Link To PCM
Body(Body Control Module)	Battery Saver Shut Down Time
Body(Body Control Module)	Ignition Off Courtesy Lamp
Body(Body Control Module)	Key Program
Body(Body Control Module)	Options
Body(Body Control Module)	Pre Delivery Mode
Body(Body Control Module)	Rear Wiper Control
Body(Body Control Module)	Set Key To Priority 1
Body(Body Control Module)	Twilight Sentinel
Body(Body Control Module)	Two Stage Unlock
Body(Body Control Module)	User Settings
Body(HVAC (Heating Ventilation And Cooling))	Blower Operating Time Reset
Body(HVAC (Heating Ventilation And Cooling))	Calibrate HVAC Doors
Body(HVAC(Heating Ventilation and Cooling))	Blower Operating Time Reset
Body(HVAC(Heating Ventilation and Cooling))	Calibrate HVAC Doors
Body(IPC (Instrument Panel Cluster))	Reset Service Interval
Body(IPC(Instrument Panel Cluster))	Reset Service Interval
Body(Instrument)	Configuration
Body(Instrument)	Fuel Gauge Calibration
Body(Instrument)	Instrument Configuration
Body(Instrument)	Options
Body(Instrument)	Reset Service Interval
Body(Instrument)	Reset Trip Computer Settings
Body(Instrument)	Reset User Calibration
Body(Instrument)	Reset to Vehicle Build Settings
Chassis(EBCM (Electronic Brake Control Module))	Brake Pressure Sensor Calibration
Chassis(EBCM (Electronic Brake Control Module))	Calibrate Steering Angle Sensor
Engine(V6 Engine)	Crankshaft Pos. System Var. Reset
Engine(V6 Engine)	Fuel Trim Reset
Engine(V6 Engine)	Idle Learn
Engine(V6 Engine)	Oil Life Reset
Engine(V6 Engine)	Reset Engine Oil Life
Engine(V6 Engine)	Throttle Body Relearn
Engine(V8 GEN III)	Reset Engine Oil Life
Engine(V8 GEN IV)	Reset Engine Oil Life
Infotainment System(SIC (Secondary Information Centre))	Display Type
Infotainment System(SIC (Secondary Information Centre))	Learn VIN
SIC (Secondary Information Centre)	Display Type
SIC (Secondary Information Centre)	Learn VIN
Transmission(Automatic Transmission)	Configuration
Transmission(Automatic Transmission)	Fuel Gauge Calibration
Transmission(Automatic Transmission)	Reset Adaptive Values
Transmission(Automatic Transmission)	Reset Service Interval
Transmission(Automatic Transmission)	Reset Trip Computer Settings