

PEUGEOT V13.0

Table of Contents

1	Vehicle models covered.....	1
2	Vehicle systems covered.....	2
3	Vehicle Special Function covered.....	3

1 Vehicle models covered

Model	Year
1007 VAN	Up to 2013
106R	Up to 2013
107	Up to 2013
206	Up to 2013
206 MUX	Up to 2013
206+	Up to 2013
207	Up to 2013
207	Up to 2013
207 Diesel	Up to 2013
207 VAN	Up to 2013
207i	Up to 2013
306	Up to 2013
306R	Up to 2013
307	Up to 2013
307 CAN	Up to 2013
307 VAN	Up to 2013
308	Up to 2013
4007	Up to 2013
405	Up to 2013
406	Up to 2013
406R	Up to 2013
406R Coupe	Up to 2013
407	Up to 2013
408	Up to 2013
607	Up to 2013
806	Up to 2013
807 VAN	Up to 2013
BOXER	Up to 2013
BOXER 3	Up to 2013
EXPERT	Up to 2013
PARTNER	Up to 2013
PARTNER 2	Up to 2013

2 Vehicle systems covered

System	DTC	Data List	Active Test	Special Func
ABS	X	X	X	X
ABS + TRACT. CONTROL	X	X	X	
ABS/ESP	X	X	X	
AIRBAG	X	X		
AT	X	X	X	X
Air Conditioning	X	X	X	
Airbag	X	X	X	
Alarm	X	X	X	
Auto Gearbox	X	X	X	X
Automatic transmission control unit	X	X	X	
BSI	X	X		
Built-In System	X	X	X	X
Built-in system interface	X	X	X	X
CD Player	X	X	X	
CD player On-board	X	X	X	
Diesel Engine	X	X	X	X
Diesel fuel additive control unit	X	X	X	
Display/Telematics	X	X	X	
Driver's door module	X	X	X	
Driving school		X	X	
Engine	X	X	X	X
Gearbox	X	X		
Hand Free Kit	X	X	X	
ICM	X	X	X	
Instrument Panel	X	X	X	
Multi-function display	X	X	X	
On-board navigation system	X	X	X	
Parking assistance	X	X	X	
Parking brake	X	X		
Passenger door module	X	X	X	
Petrol Engine	X	X	X	X
Power Steering	X	X		
Radio	X	X	X	
Rain/brightness sensor	X			
Roll-over ECU	X	X		
SERVICE LIGHT RESET				X
Seat and mirrors with memory	X	X		
Sliding side doors module	X	X		
Steering column module	X	X	X	
Steering wheel switching module	X	X	X	
Sun roof	X	X	X	
navigation system	X	X		

3 Vehicle Special Function covered

System	Special Function
ABS	Bleeding
ABS	Brake air bleed
ABS	Steering angle calibration
AT	Initialization the auto adaptive
Auto Gearbox	Initialization the auto adaptive
Built-In System	Configuration
Built-In System	Forcing of the customer mode
Built-In System	Resetting to zero of the service mileage
Built-In System	Resetting zero service
Built-in system interface(BSI)	Forcing of the customer mode
Built-in system interface(BSI)	Resetting to zero of the service mileage
Desel Engine	EGR SV learning
Desel Engine	EGR throttle learning
Desel Engine	Initializ. FAP filter additive quantity
Desel Engine	Initialization turbo limit
Desel Engine	Particle filter regeneration
Desel Engine	Particle filter replacement
Desel Engine	Replace metering pump
Desel Engine	Replace or fill additive tank
Desel Engine	Tank filling
Diesel Engine	Particle filter regeneration
Diesel Engine	Particle filter regeneration(moving)
Diesel Engine	Particle filter regeneration(stationary)
ENGINE	EGR SV learning
ENGINE	EGR throttle initial. and intake air heat.
Engine	EGR SV learning
Engine	EGR throttle learning
Engine	Initializ. FAP filter additive quantity
Engine	Initialization turbo limit
Engine	Particle filter regeneration
Engine	Particle filter replacement
Engine	Replace metering pump
Engine	Replace or fill additive tank
Engine	Tank filling
Petrol Engine	Initialization the auto adaptive
SERVICE LIGHT RESET	1.Service Reset
SERVICE LIGHT RESET	Service Reset